



FUTERA II INSTALLATION AND OPERATION INSTRUCTIONS

Figure 14A - Low Temperature Boiler Piping
(See Notes and Adjustment Procedures)



Notice: These drawings show suggested piping configuration and valving. Check with local codes and ordinances for specific requirements.