



Note: Float switch is made and activates the pump at the 5" water level from the bottom of the tank.

Ratings & Dimensions (in inches)																
Model	мвн	GPH	L	W	H1	H2	1	C 1	C2	2	l1	12	3	01	4	02
NB-6P	6000	48	22	141/4	12 3/4	8 3/8	Cap 5" port	4	4 3/4	Inlet 3/4" port	7	9 1/2	Inlet 1" port	1 3/4	Outlet 3/8" port	4 1/2